

## *iConverter*® 2FXM2 Standalone Module Quick Start



#### **Product Overview**

The iConverter 2FXM2 Network Interface Device (NID) with integrated management provides Fast Ethernet (100BASE-FX) fiber-to-fiber media conversion.

The 2FXM2 has built-in Operation Administration and Maintenance (OAM) functionality enabling the 2FXM2 to operate as a managed demarcation point at the customer premises and network edge, offering Quality of Service canabilities

The 2FXM2 supports IPv4 addressing, IP-Less protocol using the 802.3ah OAM channel, SNMPv1/v2c/v3, Telnet and serial console port.

See data sheet for available models.

#### **DIP-Switches**

### **DIP-Switch Bank 1**

The location of the DIP-switches is shown in below.



DIP-switch Location

The functions of DIP-switch Bank 1 are outlined in below.

Switch	Down (Factory Default)	Up
SW1	Off: Pause Disable	PAUS: Pause Enable
SW2	FDX: Port 1 Full-Duplex	HDX: Port 1 Half-Duplex
SW3, SW4	Reserved	Reserved
SW5	FDX: Port 2 Full-Duplex	HDX: Port 2 Half-Duplex
SW6 - SW8	See Link Mode Selection	

DIP-switch BANK 1 Definitions

#### SW1 - Fiber Pause

When this DIP-switch is in the Down "OFF" position, Pause is disabled. When the DIP-switch is in the Right "PAUS" position Pause is enabled.

When a port is configured for Auto-Negotiation (AN), Pause operation is determined during the negotiation process between itself and the link partner. The port advertises its Pause capability (Symmetrical or No Pause) based on the Pause Disable/Enable DIP-switch setting.

When a port is operating in Manual mode (MAN), its Pause operation mode is based on the Pause Disable/Enable DIP-switch setting

### SW2 - Port 1 Full/Half Duplex

Setting this DIP-switch to Half-Duplex "HDX" facilitates a connection that supports Half-Duplex. Setting this DIPswitch to Full-Duplex "FDX" facilitates a connection that supports Full-Duplex operation.

#### SW3 and SW4 - Reserved

These DIP-switches are for factory use only and must always remain in the Down position (factory default).

Page 2

AC Adapter

## SW5 - Port 2 Full/Half Duplex

Setting this DIP-switch to Half-Duplex "HDX" facilitates a connection that supports Half-Duplex. Setting this DIPswitch to Full-Duplex "FDX" facilitates a connection that supports Full-Duplex operation.

#### SW6, SW7, SW8 - Link Modes

These three DIP-switches configure the link mode settings. It is recommended to have link modes Down (default) during the initial installation. After the circuit has been tested and operational, configure the module for the desire mode

For detailed information on the operation of the different Link Modes, download the application note "iConverter

SW6	SW7	SW8	Link Mode Selection
Down	Down	Down	Link Segment (LS) (Factory Default)
Up	Down	Down	Link Propagate (LP)
Down	Up	Down	Remote Fault Detect + Link Segment (RFD + LS)
Up	Up	Down	Remote Fault Detect + Link Propagate (RFD + LP)
Down	Down	Up	Symmetrical Fault Detect (SFD)
Up	Down	Up	Asymmetrical Link Propagate Port 1 to Port 2 (ALP P1-P2)
Down	Up	Up	Asymmetrical Link Propagate Port 2 to Port 1 (ALP P2-P1)
Up	Up	Up	Asymmetrical RFD + LP

Link Modes

Page 3

## Page 1

## **Specifications**

Description	iConverter <b>2FXM2</b> 100BASE-X Fiber to 100BASE-X Fiber Media Converter and Network Interface Device		
Standard Compliances	IEEE 802.3, 802.1Q, 802.1p, 802.1ad, 802.3ah RFC 2819 (RMON), 2863, 2131 MEF 9, 14, 21		
Regulatory Compliances	Safety: UL, CE, NEBS Level 3, UKCA EMI: FCC Class A ACT: TAA, BAA, NDAA		
Environmental	RoHS, WEEE, REACH		
Management	IPv4, Telnet, SNMPv1, SNMPv2c, SNMPv3, Serial Console		
Frame Size	Up to 2,048 bytes		
Port Types	Fiber: 100BASE-X (SFP) Serial: RS-232 (Mini DIN-6 female) Mini DIN-6 to DB-9 adapter included		
Cable Types	Fiber: Multimode: 50/125μm, 62.5/125μm Single-mode: 9/125μm Serial: RS-232, 22 to 24 AWG, 12 to 50 pF/ft		

AC Power Requirements	AC Adapter: 100 - 240VAC/50 - 60Hz, 0.08A @ 120VAC (max)		
DC Power	DC Input (Terminal): +8 to +15VDC, 0.6A @ 9VDC 2-Pin Terminal (non-isolated)		
Requirements	DC Input (AC Adapter): +8 to +15VDC, 0.6A @ 9VDC 2.5mm Barrel Connector		
Dimensions W x D x H	Standalone: 3.1" x 4.8" x 1.0" (78.7 mm x 121.9 mm x 25.4 mm) Standalone with Mounting Brackets: 3.8" x 4.8" x 1.0" (96.5 mm x 121.9 mm x 25.4 mm)		
Weight	1.0 lb. (453.6 grams) - without AC Adapter 1.5 lbs. (680.4 grams) - with AC Adapter		
Temperature	Commercial: Wide: Extended: Storage:	0 to 50°C -40 to 60°C -40 to 75°C -40 to 80°C	
Humidity	5 to 95% (non-condensing)		
Altitude	-100m to 4,000m		
MTBF (hrs)	500,000 - Module 250,000 - Module with US Adapter 100,000 - Module with Universal Adapter		
Warranty	Lifetime warranty and 24/7/365 free Technical Support		

## **General and Copyright Notice**

This publication is protected by U.S. and international copyright laws. All rights reserved. The whole or any part of this publication may not be reproduced, stored in a retrieval system, translated, transcribed, or transmitted, in any form, or by any means, manual, electric, electronic, electromagnetic, mechanical, chemical, optical or otherwise, without prior explicit written permission of Omnitron Systems Technology, Inc.

The following trademarks are owned by Omnitron Systems Technology, Inc.: FlexPoint™, FlexSwitch™, iConverter®, miConverter™, NetOutlook®, OmniLight®, OmniConverter®, RuggedNet®, Omnitron Systems Technology, Inc.™, OST™ and the Omnitron logo.

All other company or product names may be trademarks of their respective owners

The information contained in this publication is subject to change without notice. Omnitron Systems Technology, Inc. is not responsible for any inadvertent errors.

## Warranty

This product is warranted to the original purchaser (Buyer) against defects in material and workmanship for a period of two (2) years from the date of shipment. A lifetime warranty may be obtained by the original purchaser by registering this product at www.omnitron-systems.com/ support within ninety (90) days from the date of shipment. During the warranty period, Omnitron will, at its option, repair or replace a product which is proven to be defective with the same product or with a product with at least the same functionality.

For warranty service, the product must be sent to an Omnitron designated facility, at Buyer's expense. Omnitron will pay the shipping charge to return the product to Buyer's designated US address using Omnitron's standard shipping method.

## **Limitation of Warranty**

The foregoing warranty shall not apply to product malfunctions resulting from improper or inadequate use and/or maintenance of the equipment by Buyer Buyer-supplied equipment, Buyer-supplied interfacing, unauthorized modifications or tampering with equipment (including removal of equipment cover by personnel not specifically authorized and certified by Omnitron), or misuse, or operating outside the environmental specification of the product (including but not limited to voltage, ambient temperature, radiation, unusual dust, etc.), or improper site preparation or maintenance.

**Software Controlled Switch Settings** 

Additional settings are available via software control.

Software or other third-party SNMP-based clients:

**DIP-switch Configuration** 

MIB statistics

Bits Per Second

Hardware Flow Control

The default password is public.

the module is 192.168.1.220.

Stop Bits

Data Bits

Parity

Port 1 and Port 2 Configuration

Bandwidth control (rate limiting)

serial interface with the following settings.

The following software settings can be controlled via

Serial Console/Telnet Console, NetOutlook Management

802.1ad Q-in-Q, QoS and Port Access Control

Configurable Link Fault Propagation modes

The module can be configured by attaching the serial

port to a DB-9 serial (RS-232) equipped computer with

terminal emulation software such as ProComm or Putty.

The Serial Console Port (DCE) is a mini DIN-6 female

connector which can be changed to a DB-9 connector with

the included adapter. Attach the ends of a serial cable to

the serial port of the PC and the Serial Console Port of

the module. The port is a standard RS-232 asynchronous

When using Telnet or SNMP, the default IP address for

For more information on using and configuring the

Management Software user manual or the 2FXM2 full

Page 4

Advanced Features, register for access to the Ne

57,600

NONE

NONE

No other warranty is expressed or implied. Omnitron specifically disclaims the implied warranties of merchantability and fitness for any particular purpose.

The remedies provided herein are the Buyer's sole and exclusive remedies. Omnitron shall not be liable for any direct, indirect, special, incidental, or consequential damages, whether based on contract, tort, or any legal theory.

## **Environmental Notices**

The equipment covered by this manual must be disposed of or recycled in accordance with the Waste Electrical and Electronic Equipment Directive (WEEE Directive) of the European Community directive 2012/19/EU on waste electrical and electronic equipment (WEEE) which, together with the RoHS Directive 2015/863/EU, for electrical and electronic equipment sold in the EU after July 2019. Such disposal must follow national legislation for IT and Telecommunication equipment in accordance with the WEEE directive: (a) Do not dispose waste equipment with unsorted municipal and household waste. (b) Collect equipment waste separately. (c) Return equipment using collection method agreed with Omnitron

## **Mounting and Cable Attachment**

Caution: Use proper ESD protection to reduce the risk of damage to your equipment.

a. The module is available as a standalone module with integrated wall-mount brackets. Attach the unit to a wall. backboard or other flat surfaces. Make sure the unit is placed in a safe, dry and secure location

#### For AC models:

To power the unit using the AC/DC adapter, connect the AC/DC adapter to an AC outlet. Then connect the barrel plug at the end of the wire on the AC/DC adapter to the 2.5mm DC barrel connector (center-positive) on the unit. Confirm that the unit has powered up properly by checking the power status LED located on the front of the unit.

#### For DC Models:

To power the unit using a DC power source, prepare a power cable using a two conductor insulated wire (not supplied) with 12AWG to 20AWG thickness. Cut the power cable to the length required. Strip approximately 3/8 of an inch of insulation from the power cable wires. Connect the power cables to the unit by fastening the stripped ends to the DC power connector.

Connect the power wires to the DC power source. The Power LED should indicate the presence of power.

WARNING: Note the wire colors used in making the positive and negative connections. Use the same color assignment for the connection at the DC power source.

## NOTE: If mounting with a safety ground attachment, use the safety ground screw at the rear of the unit.

b. Insert the SFP fiber transceivers into the SFP receptacles on the module

### NOTE: The release latch of the SFP transceiver must be in the closed (up) position before insertion.

d. Connect an appropriate multimode or single-mode fiber cables to the fiber ports of the installed module. It is important to ensure that the transmit (TX) is attached to the receive side of the device at the other end and the

Page 5

The equipment is marked with the WEEE symbol

shown to indicate that it must be collected separately from

other types of waste. In case of small items the symbol

may be printed only on the packaging or in the user

manual. If you have questions regarding the correct

disposal of equipment go to www.omniton-systems.com/

support or e-mail to Omnitron at intlinfo@omnitron-

ATTENTION: Observe precautions for handling

WARNING: Risk of electrical shock.

WARNING: Potential damage to equipment and

systems.com.

personal injury.

Safety Warnings and Cautions

electrostatic discharge sensitive devices

Page 6

receive (RX) is attached to the transmit side. Single-fiber (SF) media converter models operate in pairs. The TX

wavelength must match the RX wavelength at the other

end and the RX wavelength must match the TX wavelength

NOTE: In order to support Remote OAM Management

Mode. Port 1 of the 2FXM2 must be connected to the

Description

OFF: No power applied or faulty

Blinking Green: Data activity

Blinking Green: Data activity

ON: Module has power

OFF: No fiber link

OFF: Half-Duplex

OFF: No fiber link

OFF: Half-Duplex

ON: Full-Duplex

ON: Full-Duplex

Port 1 on the 2FXM2 or link partner.

Color

Green

Green

Green

Green

Green

at the other end

**LED Indicators** 

LED

"PWR"

P1 Activity

P1 Duplex

"FDX"

P2 Activity

"FO"

P2 Duplex

"FDX"

"FO"

# **Customer Support Information**

Fax: (949) 250-6514

Address: Omnitron Systems Technology, Inc.

38 Tesla

support@omnitron-systems.com www.omnitron-systems.com

040-8940N-001C 4/23

(949) 250-6510 Phone:

Irvine, CA 92618, USA

Page 11 Page 7 Page 9 Page 10 Page 12 Page 8